

QUER[®]

Owner's manual

MP3 player


KOM0547

KOM0556

KOM0557

KOM0634

KOM0635



Safety instructions

1. Prior to device use, please read the manual and follow its instructions. Producer will not take responsibility for any damages which occurred due to inappropriate device use.
2. Any conservation activities should not be carried out on device while in use.
3. Device must be used only inside. Device is not suitable to be used outside.
4. Protect device from humidity (also, when not in use).
5. This device is not suitable for children nor persons with limited physical, sensor or psychological capabilities; neither for persons who lacks experience on how to use device, unless performed while accompanied by other person/s responsible for their safety. Children should not use the device as a toy.
6. Due to safety reasons, in case of damage, device can be repaired by qualified persons or specialist repairing workshop exclusively.
7. The device should not be used in vicinity of inflammable products.

Description

Quer MP3 Player with MicroSD card reader function.

- Lightweight and portable MP3 player
- microSD card reader (up to 32GB)
- No built-in memory (microSD card)
- Clip allows you to attach the player to your belt for example.
- Supported formats MP3,WAV,WMA
- The ability to skip tracks, switching, adjust the volume.
- Automatically start playing after inserting the card.
- Built-in battery.
- Charging via miniUSB cable.

Package contents:


MP3 player

Headphones

miniUSB cable

Specifications are subject to change without notice.

Buttons and functions



Power On/Off

To power on device, slide power switch to the **ON** position. To power off device, slide power switch to the **OFF** position.

Volume adjustment

To increase volume, shortly press the **Volume +** button. To decrease volume, shortly press the **Volume -** button.

English



Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Made in China for LECHPOL Zbigniew Leszek, Miętne, 1 Garwolińska Street, 08-400 Garwolin.

